

# SF1A Sump Foot Installation Manual

## for CIS Series, S2 Series, and SI Series



Attaching the sump foot to the pump is easy and done in a few simple steps.

1. Place the sump foot on the bottom of the pump.
2. Align the screw slots in the sump foot with the screw holes on the pump.
3. Insert the three screws provided (10-24 x 1" machine Phillips pan-head) through the sump foot and into the pump and tighten.

# SF1A Sump Foot Installation Manual

## for ST Series and S3 Series



Attaching the sump foot to the pump is easy and done in a few simple steps.

1. Place the sump foot on the bottom of the pump.
2. Align the screw slots in the sump foot with the screw holes on the pump.
3. Insert the three 14 x  $\frac{3}{4}$ " sheet metal Phillips pan-head screws through the small slot in the sump foot and into the hole of the ST Series pump (ST1033 or ST1050) or directly into the plastic strainer of the S3 Series pump (S3033 or S3050)